

# Table of Contents

Introduction	i		
CHAPTER 1			
1. <b>CDQPrima</b> Overview	1-1		
1.1 Model 110 Description	1-4		
1.2 Model 120 Description	1-4		
1.3 Model 210 Description	1-5		
1.4 Model 220 Description	1-5		
1.5 Model 230 Description	1-5		
1.6 <b>CDQPrima</b> Features	1-5		
1.6.1 Mechanical Features	1-6		
1.6.2 Audio and Time Code	1-6		
1.6.3 Ancillary Data	1-7		
1.6.4 Audio Compression	1-8		
1.6.5 Control Features	1-8		
1.6.6 Pre-Programmed Quick-Configurations	1-9		
1.6.7 Auto Detection of Incoming Calls	1-10		
1.6.8 On-Site Software Upgrades	1-10		
1.6.9 Digital Interface Modules	1-10		
CHAPTER 2			
2. Unpacking & Inspection	2-1		
2.1 Location of Units	2-1		
2.2 Environmental Considerations	2-1		
2.3 Configuration Dependencies	2-2		
2.4 Remote Control Considerations	2-2		
2.4.1 Remote Control of Models 110 and 120	2-2		
2.4.2 Remote Control of Models 210, 220, and 230	2-3		
CHAPTER 3			
3. <b>CDQPrima</b> Connections	3-1		
3.1 Connections to the Network	3-1		
3.1.1 V.35 Using the DIF102 Digital Interface Module	3-2		
3.1.2 X.21, RS422/RS449 Using the DIF101 Digital Interface Module	3-2		
3.1.3 ISDN Using the TA101 Digital Interface Module	3-4		
3.1.4 ISDN Using the TA201 or TA301 Digital Interface Module	3-4		
3.2 Rear Panel Connectors	3-5		
3.2.1 Power & Power Switch (1, 2)	3-5		
3.2.2 Analog Audio I/O (3, 4)	3-5		
3.2.3 Digital Interface Module Ports (5)	3-7		
3.2.4 Alarm Port (6)	3-7		
3.2.5 Remote Control Port (7)	3-7		
3.2.6 Ancillary Data Port (8)	3-7		
3.2.7 AES/EBU Digital Audio I/O (9, 10)	3-7		
3.2.8 S/PDIF Digital Audio I/O (9, 10)	3-8		
3.2.9 Opto/Relay I/O (100 Series) (11)	3-8		
3.2.10 RS232 Port (200 Series) (12)	3-8		
3.2.11 Sync Data (200 Series) (13)	3-8		
3.2.12 RS485 Port (200 Series) (14)	3-9		
3.2.13 SMPTE Time Code (200 Series) (15)	3-9		
3.2.14 Relay Outputs (200 Series) (16)	3-9		
3.2.15 Optically Isolated Inputs (200 Series) (17)	3-9		
3.2.16 Optical Digital Audio I/O (18)	3-9		
CHAPTER 4			
4. The <b>CDQPrima</b> Keypad and Display	4-1		
4.1 Character Display (Models 110, 120, 210 & 220)	4-1		
4.2 Graphics Display (Model 230)	4-2		
4.3 Front Panel Controls	4-2		
4.3.1 Cursor Keys (All Models)	4-3		
4.3.2 Alphanumeric Keypad (All Models)	4-3		
4.3.3 Dial Keypad (All Models)	4-3		
4.3.4 Dial Setup Keys (All Models)	4-4		
4.3.5 Menu Keys (Models 120, 220 & 230 only)	4-5		
4.3.6 Headphone Keys (Models 120, 220 & 230 only)	4-5		
4.3.7 Cue Keys (Models 120, 220 & 230 only)	4-6		

4.3.8 Level Control Keys (Model 230)	4-7	5. Command and Control Summary	5-1
4.3.9 Measurement Keys (Model 230 only)	4-7	5.1 Menu Navigation using Keypad and Display	5-3
4.3.10 Function Keys (Model 230 only)	4-8	5.2 Computer or Terminal Control	5-4
4.4 Front Panel Status Indicators	4-8	5.3 Windows® Control	5-5
4.4.1 Encoder and Decoder Status LEDs	4-9	5.4 Command Summary—Basic Operation	5-6
4.4.1.1 PLL	4-9	5.4.1 Digital Interface and Terminal Adapter Setup	5-6
4.4.1.2 MONO	4-9	5.4.1.1 Digital Interface Setup	5-6
4.4.1.3 DMONO	4-9	5.4.1.2 Digital Interface Status	5-8
4.4.1.4 JSTEREO	4-9	5.4.1.3 Terminal Adapter TA101 Configuration.	5-8
4.4.1.5 STEREO (230 only)	4-9	5.4.1.4 Terminal Adapter TA201 and TA301 Configuration for North America	5-13
4.4.1.6 MUSICAM	4-9	5.4.1.5 Terminal Adapter TA201 Configuration, Non-North American Operation	5-16
4.4.1.7 G.722	4-9	5.4.1.6 Other TA Parameters	5-19
4.4.1.8 AES/EBU (Encoder only)	4-9	5.4.1.7 Terminal Adapter Configuration Storage and Recall	5-20
4.4.1.9 ANALOG (Encoder only)	4-10	5.4.2 Automatic Encoder and Decoder Configuration using Quick Configurations	5-21
4.4.1.10 SUM (230 only)	4-10	5.4.3 Manual Encoder Configuration	5-23
4.4.1.11 ACE (230 only)	4-10	5.4.3.1 Audio Source Selection	5-23
4.4.1.12 DPLL (230 only)	4-10	5.4.3.2 Algorithm, Mode, Bit Rate and Sample Rate Selection	5-24
4.4.1.13 CCS (230 only)	4-10	5.4.4 Manual Decoder Configuration	5-26
4.4.1.14 Display:ALG1 (230 only)	4-10	5.4.5 Speed Dialing and Directory Maintenance (Terminal Adapter Only)	5-28
4.4.1.15 H.221 (230 only)	4-11	5.4.6 Manual Dialing and Connection Status (TA Only)	5-30
4.4.1.16 CCSIMUX (230 only)	4-11	5.4.7 Remote Control Configuration	5-31
4.4.1.17 FRAMED (decoder only)	4-11	5.4.7.1 Remote Control (Rear Panel - All Models)	5-32
4.4.1.18 BER (Decoder only)	4-11	5.4.7.2 Front Panel Remote Control (Models 120, 220, 230)	5-33
4.4.2 Status	4-11	5.4.8 Loopback	5-34
4.4.2.1 SCUE1	4-11	5.4.9 Headphones (models 120, 220 and 230 only)	5-35
4.4.2.2 RCUE1	4-11	5.4.10 Status and Level Display (models 120, 220 and 230 only)	5-36
4.4.2.3 DIF1, DIF2, DIF3, DIF4, DIF5 and DIF6	4-11	5.4.11 FFT (Spectrum Analyzer) and Phase Display (Model 230 Only)	5-38
4.4.3 Level LEDs (Model 120, 220 & 230 only)	4-12	5.4.12 Hot Keys (Model 230 only)	5-38
4.4.3.1 Peak & Average Level LEDs	4-12	5.4.13 Fan Control, Display Contrast, Keypad Beeper and Audible Alarm	5-39
4.4.3.2 Stereo Image Display	4-12		
4.4.3.3 Correlation Display	4-12		
4.4.3.4 Message Display	4-12		
4.4.3.5 Selective Dimming	4-12		
4.4.3.6 Headphone Status Indicators (Model 120, 220 & 230 only)	4-12		
4.5 Front Panel Connectors	4-13		
4.5.1 Headphone Jack (Model 120, 220 & 230 only)	4-13		
4.5.2 Front Panel Remote Control Port (Model 120, 220 & 230 only)	4-13		

CHAPTER 6

6. Codec Compression Algorithms and Modes	6-1
6.1 Stereo and Dual Mono	6-1
6.2 Joint Stereo	6-1
6.3 ISO/MPEG Layer III	6-2
6.4 MUSICAM and ISO/MPEG Layer II	6-3
6.5 G.722	6-3
6.6 Algorithm, Mode, Bit and Sample Rate	6-3
6.7 Pre-Programmed Quick Configurations	6-5
6.7.1 Entry 0 CDQ1000_24:QS	6-7
6.7.2 Entry 1 CDQ2002LNS:QS	6-7
6.7.3 Entry 2 H221_2LINES:QS	6-7
6.7.4 Entry 3 H221_4LINES:QS	6-7
6.7.5 Entry 4 H221_6LINES:QS	6-7
6.7.6 Entry 5 MICRO56:QS	6-7
6.7.7 Entry 6 G.722_56:QS	6-8
6.7.8 Entry 7 G.722_64:QS	6-8
6.7.9 Entry 8 MPEGL2/64K:QS	6-8
6.7.10 Entry 9 MPEGL2/56K:QS	6-8
6.7.11 Entry 10 CCSN/64K:QS	6-8
6.7.12 Entry 11 CCSTEST64	6-8
6.7.13 Entry 12 CCSTEST128	6-9
6.7.14 Entry 13 CCSTESTH221	6-9
6.7.15 Entry 14 CCSTEST56	6-9
6.7.16 Entry 15 CCSTEST112	6-9
6.7.17 Entry 16 CDQ1000/56K:QS	6-9
6.7.18 Entry 17 CDQ2000/112:QS	6-9
6.7.19 Entry 18 CCSN/56K:QS	6-9
6.7.20 Entry 19 G.722_H.221:QS	6-9
6.7.21 Entry 20 CCSN/128K:QS	6-10
6.7.22 Entry 21 CCSN/112K:QS	6-10
6.7.23 Entry 22 CDQ2001/128:QS	6-10
6.7.24 Entry 23 CDQ2001/112:QS	6-10
6.7.25 Entry 24 ZEPHYR/56K:QS	6-10
6.7.26 Entry 25 ZEPHYR/64K:QS	6-10
6.7.27 Entry 26 ZEPHYR/112K:QS	6-10
6.7.28 Entry 27 ZEPHYR/128K:QS	6-10
6.7.29 Entry 28 LYR3/56K:QS	6-11
6.7.30 Entry 29 LYR3/64:QS	6-11
6.7.31 Entry 30 LYR3IND56:QS	6-11
6.7.32 Entry 31 LYR3IND64:QS	6-11

APPENDIX A

Menu Tree	1
-----------	---

# Index

## A

AES/EBU, 2-2  
Alarms, 3-7  
Algorithm mode, 6-3  
  Dual Mono, 6-1  
  Joint Stereo, 6-1  
  Stereo, 6-1  
Algorithms, 6-3, 6-5  
  G.722, 1-8, 6-3  
  Layer II, 1-8, 6-3  
  Layer III, 1-8, 6-2  
  MUSICAM, 1-8, 6-3  
Ancillary data, 1-7, 1-9, 3-7,  
  3-8, 3-9  
  Bit rates, 1-7  
  Mux mode, 1-7  
  Nomux mode, 1-7  
  RS232, 3-7, 3-8  
  Time code, 3-9  
Audio I/O, 3-5, 3-7, 3-8, 3-9,  
  5-23, 5-26, 5-28  
Auto detection, 1-10

## B

Bit rates, 4-4, 6-3

## C

Cable lengths, 2-2  
Cables  
  Ancillary data, 3-7  
  Digital audio, 2-2, 3-8  
  Opto-isolators, 3-9  
  Relay, 3-9  
  Remote control, 3-7, 5-4,  
    5-31  
CDQ1000, 4-10

CDQ2000, 4-10, 4-11  
Commands, 5-6  
  CAA, 5-19  
  CAC, 5-19  
  CBR, 5-34, 5-35  
  CBZ, 5-39  
  CCD, 5-30, 5-31  
  CCR, 5-30, 5-31  
  CCS, 5-30, 5-31  
  CCV, 5-39  
  CDC, 5-30, 5-31  
  CDI, 5-30  
  CDS, 5-22, 5-23, 5-28, 5-29  
  CDT, 5-6, 5-7  
  CFB, 5-33, 5-34  
  CFE, 5-33, 5-34  
  CFN, 5-39  
  CFP, 5-33, 5-34  
  CHK, 4-8, 5-38  
  CHP, 5-35  
  CHU, 4-5, 5-30  
  CIB, 5-9, 5-12  
  CID, 5-32  
  CIE, 5-8  
  CIF, 4-4, 5-6, 5-7  
  CIS, 5-8  
  CLB, 5-19, 5-20, 5-34, 5-35  
  CLC, 5-9, 5-12  
  CLD, 5-9, 5-11, 5-14, 5-15,  
    5-17  
  CLI, 4-12, 5-36, 5-37  
  CLL, 5-9, 5-17  
  CLM, 5-36, 5-37  
  CPC, 5-32, 5-33  
  CRB, 5-32, 5-33  
  CRD, 5-19, 5-30  
  CRE, 5-32, 5-33  
  CRI, 5-32  
  CRM, 5-32  
  CSA, 5-9, 5-12, 5-14, 5-16,  
    5-17

CSC, 5-22, 5-23, 5-28  
CSD, 4-4, 5-22, 5-28, 5-29  
CSE, 4-5, 5-22, 5-28, 5-29  
CSF, 5-22, 5-28, 5-29  
CSI, 5-9, 5-11, 5-14, 5-15  
CSL, 5-34, 5-35  
CSN, 5-22, 5-28, 5-29  
CSW, 5-9, 5-10, 5-14, 5-15,  
  5-17  
CTA, 5-20, 5-21  
CTB, 5-20, 5-21  
CTC, 5-19, 5-20  
CTD, 5-20, 5-21  
CTE, 5-20, 5-21  
CTF, 5-9, 5-12, 5-14, 5-16,  
  5-17  
CTN, 5-20  
CTO, 5-19, 5-30  
CTP, 5-19, 5-20  
CTR, 5-9, 5-13, 5-14, 5-16,  
  5-17, 5-18  
CVU, 5-36  
DAL, 5-26, 5-27  
DBR, 5-26, 5-27  
DCO, 5-26, 5-28  
DCS, 5-26, 5-28  
DHV, 5-35  
DIN, 5-26, 5-27  
DLI, 5-26, 5-27  
DMU, 5-26, 5-28  
DSS, 5-26, 5-28  
EAI, 5-23  
EAL, 5-23, 5-24  
EAM, 5-23, 5-24  
EBR, 5-23, 5-25  
ECS, 5-23  
EHV, 5-35  
ELI, 5-23, 5-25  
EMM, 5-23, 5-24  
ESR, 5-23  
ESS, 5-23, 5-26

ETI, 5-23, 5-24  
MBX, 5-39  
MTM, 5-38  
Cooling fan, 5-39

## D

Decoder, 5-26  
  Algorithm, 5-26, 5-27  
  Algorithm mode, 5-28  
  Bit rate, 5-26, 5-27  
  Copy/Swap, 5-26  
  Independent, 5-26  
  Line format, 5-26, 5-27  
  Mute, 5-26, 5-28  
  Status, 5-26, 5-28  
Dialing, 4-3  
  Call termination, 4-5, 5-30  
  Manual, 4-4, 5-30  
  Speed dial, 4-4, 5-28  
DIF101, 3-2, 5-7  
DIF102, 3-2, 5-7  
Digital audio, 3-7, 3-8, 3-9,  
  5-23, 5-24  
Digital Interface Module, 1-  
  10, 3-2, 3-4, 3-7, 5-  
  6, 5-8  
Display  
  ACE LED, 4-10  
  AES/EBU LED, 4-9  
  ALG1 LED, 4-10  
  Analog LED, 4-10  
  BER LED, 4-11  
  CCS LED, 4-10  
  CCSIMUX LED, 4-11  
  Character, 4-1  
  Contrast, 4-1, 5-39  
  Correlation, 1-4, 1-6, 4-7,  
    4-12, 5-36, 5-37  
  DIF LEDs, 4-4, 4-11, 5-8  
  DPLL LED, 4-10  
  Dual mono LED, 4-9  
  Encoder Status, 4-9  
  Framed LED, 4-11  
  G.722 LED, 4-9  
  Graphics, 4-2, 4-7  
  H.221 LED, 4-11  
  Headphone LEDs, 4-5, 4-  
    12  
  Joint stereo LED, 4-9  
  LED brightness, 4-12  
  Level, 4-7, 4-12, 5-36  
  Message display, 4-12, 5-  
    37  
  Mono LED, 4-9

MUSICAM LED, 4-9  
Peak, 4-7  
Phase, 4-2, 4-8, 5-38  
PLL LED, 4-9  
RCUE LED, 4-6, 4-11  
SCUE LED, 4-6, 4-11  
Spectrum analyzer, 4-2, 4-  
  8, 5-38  
Status, 4-1, 4-8, 4-11, 5-36  
Stereo image, 1-4, 1-6, 4-  
  7, 4-12, 5-36, 5-37  
Stereo LED, 4-9  
SUM LED, 4-10

## E

Encoder  
  Algorithm mode, 5-23, 5-  
    24  
  Algorithms, 5-23  
  Audio I/O, 5-23  
  Bit rate, 5-23, 5-24  
  Copy/Swap, 5-23  
  Copy/Swap, 5-23  
  Line format, 5-23, 5-25  
  Mono mix, 5-23, 5-24  
  Quick Configurations, 5-  
    21  
  Sample rate, 5-23, 5-24  
  Status, 5-23  
  Timing, 5-23, 5-24

## F

Factory defaults, 4-8  
Fan, 5-39  
Features, 1-1  
  Algorithms, 1-1  
  Ancillary data, 1-2, 1-4, 1-  
    5, 1-7  
  Audio, 1-2, 1-6  
  Audio compression, 1-8  
  Auto detection, 1-10  
  Control, 1-3, 1-8  
  Digital audio, 1-4, 1-5, **1-7**  
  Digital Interface Modules,  
    1-10  
  Graphic display, 1-5  
  Headphone, 1-4, 1-5, 1-6  
  Keypad, 4-2  
  Mechanical, 1-2, 1-6  
  Options, 1-2  
  Quick Configuration, 1-9  
  Relays, 1-4, 1-5

Remote control, 1-4, 1-8  
Time code, 1-6, 1-7  
Front panel, 4-13

## H

H.221, 4-11  
Headphone, 4-5, 4-6, 4-13,  
  5-35  
Hot Keys, 5-38

## I

Independent mono, 5-25  
Input level, 1-7, 3-5  
Installation, 2-1  
ISDN, 1-10, 2-2, 3-4, 5-6, 5-8,  
  5-27  
ISO/MPEG Layer III, 4-9, 5-  
  24

## J

J.52, 4-11, 5-27

## K

Keypad, 1-6, 4-2, 4-3, 5-1, 5-  
  3, 5-4  
  Alphanumeric keys, 1-8, 4-  
    3, 5-1, 5-3  
  Beeper, 1-8, 4-1, 5-39  
  Cue keys, 4-6  
  Cursor keys, 1-8, 4-3  
  Dial keys, 1-8, 4-3, 4-4  
  Function keys, 4-8  
  Headphone keys, 1-8, 4-5  
  Hot keys, 1-8  
  Level keys, 4-7  
  Measurement keys, 4-7  
  Menu keys, 4-5

## L

Level LEDs, 4-7  
Loopback, 4-2, 5-19, 5-34, 5-  
  35  
  Bit rate, 5-34, 5-35  
  DIF, 5-34  
  System, 5-34, 5-35

## M

Menu  
  Navigation, 4-3  
  Tree, 4-3, 4-5, 5-1, 5-3  
Music Line, 1-10, 4-11

## N

NT-1, 3-4, 5-8, 5-13

## O

Optical isolators, 1-5, 1-9, 3-8, 3-9

## P

PLL  
  Virtual actions, 1-10  
Power switch, 3-5  
Prima Logic Language, 1-10, 4-3, 4-10, 5-1  
Psychoacoustic parameters, 1-8

## Q

Quick Configurations, 1-9, 4-4, 5-21, 6-5  
  Editing, 5-22

## R

RCUE, 4-11  
Rear panel connectors, 3-5  
Relay outputs, 3-9  
Relays, 1-9, 3-7, 3-8, 3-9  
Remote control, 2-2, 2-3, 3-7, 4-8, 4-13, 5-4, 5-

5, 5-31, 5-32, 5-33, 5-34

Far end, 1-9, 5-5, 5-20  
Inband, 1-9  
Peripheral equipment, 1-7, 1-9  
Protocol, 5-32, 5-33, 5-34  
RS232, 2-2, 2-3, 3-7, 5-4, 5-31, 5-32  
RS485, 2-2, 2-3, 3-7, 5-4, 5-5, 5-31, 5-32  
Terminal, 2-2, 5-1, 5-6  
Timer, 5-5  
Windows, 1-9, 2-2, 5-1, 5-5, 5-6, 5-12, 5-16, 5-18, 5-33  
RS232, 1-6, 3-8  
RS422, 1-10, 3-1, 3-2, 3-3, 5-7  
RS449, 3-1, 3-2  
RS485, 3-9

## S

Sampling Rates, 1-8, 6-3  
SCUE, 4-11  
Speed Dial, 1-9, 5-28, 6-5  
  Editing, 4-5, 5-28  
Status indicators, 1-6, 4-8  
Summary alarms, 3-7  
Switch type, 5-14

## T

Terminal adapter, 4-4, 5-6, 5-17  
  Auto answer, 5-19  
  Auto reconnect, 5-19  
  Configuration, 5-21  
  Connect time, 5-30, 5-31  
  Dial time-out, 5-19, 5-30  
  EAZ, 5-9, 5-12

ID, 5-9, 5-10, 5-11, 5-14, 5-15

Inband, 5-9  
Interface, 5-9, 5-12, 5-14, 5-16, 5-17, 5-18  
LLC, 5-9, 5-12, 5-17, 5-18  
Local check, 5-9, 5-10, 5-12  
Loopback, 5-19, 5-20  
MSN, 5-9, 5-11, 5-17  
Redial, 5-19, 5-30  
Reset, 5-9, 5-13, 5-14, 5-16, 5-17, 5-18  
SPID, 5-10, 5-11, 5-14, 5-15  
  SPID, 5-9  
  Sub address, 5-9, 5-12, 5-14, 5-16, 5-17, 5-18  
  Switch type, 5-9, 5-10, 5-14, 5-15, 5-17  
TA101, 3-4, 4-11, 5-7, 5-8  
TA201, 3-4, 5-7, 5-13, 5-16  
TA301, 3-4, 5-7, 5-13  
Time code, 1-5, 1-6, 3-9  
Timing, 5-23

## U

Upgrades, 1-10, 5-34

## V

V.35, 3-1, 3-2, 5-7  
Virtual actions, 1-9, 1-10

## X

X.21, 1-10, 3-1, 3-2, 3-3, 5-7

