

Table of Contents

INTRODUCTION	I		
1. OVERVIEW	1-1		
1.1 Digital Transmission Facilities	1-4		
1.1.1 Dedicated Data Service (“Nailed-Up” DDS)	1-4		
1.1.2 Switched-56	1-4		
1.1.3 ISDN Basic Rate Interface (BRI)	1-4		
1.1.4 Primary Rate ISDN (T1 & E1)	1-5		
1.1.5 Long-Distance Interconnectivity (56-to-64kb/s)	1-5		
1.1.6 International PSDN	1-5		
1.1.7 Other Digital Transmission Paths	1-6		
1.1.7.1 Spread-Spectrum	1-6		
1.1.7.2 Satellite Links	1-6		
1.1.7.3 Other Digital Transmission Systems	1-6		
2. COMPRESSION ALGORITHMS AND LINE FORMATS	2-1		
2.1 CCS MUSICAM® Digital Audio Compression	2-1		
2.1.1 MUSICAM Compression Concepts	2-2		
2.2 ISO/MPEG Layer III	2-3		
2.3 G.722	2-4		
2.4 Performance Considerations	2-5		
2.5 Tolerance to Multiple Processing	2-6		
2.6 Post Production Processing Effects	2-7		
2.7 MUSICAM, ISO/MPEG Layer II and Layer III Sample Rates and Bit Rates	2-8		
2.8 Ancillary Data	2-9		
2.9 Compatibility with older CCS codecs	2-9		
2.10 Digital Transmission Line Formats	2-10		
		2.10.1 Inverse Multiplexing Functionality: CCSIMUX and J.52	2-10
		2.10.1.1 CCSIMUX	2-10
		2.10.1.2 ITU-T J.52	2-10
		2.10.1.3 Transmission with H.221 framing	2-11
		2.10.2 Single Line Mode	2-12
		2.10.3 Independent Mono	2-12
		3. ADVANCED CONFIGURATIONS FOR CUSTOM APPLICATIONS	3-1
		3.1 Decoder Independent Mode	3-2
		3.2 Broadcast Applications	3-2
		3.2.1 Monaural Audio to Six Locations	3-2
		3.2.2 Stereo Audio to Three Locations	3-4
		3.2.3 Stereo Broadcasting to Six Locations	3-5
		3.3 Dual Algorithm Applications	3-7
		3.4 Independent Mono / Dual G.722 Operation	3-8
		3.5 Saving Your Custom Configuration	3-10
		4. ADVANCED ENCODER AND DECODER FEATURES	4-1
		4.1 Digital Audio Input and Output	4-1
		4.1.1 Selecting AES/EBU or S/PDIF Digital Audio	4-2
		4.1.2 Digital Audio Timing	4-3
		4.1.3 Operation at 44.1 kHz Sampling Rate	4-7
		4.2 Peak Level Detection	4-9
		4.3 Quiet Detection / Audio Detection	4-10
		4.4 Error Concealment	4-11
		4.5 Sine Detection	4-12
		4.6 Encoder Header and Decoder Status Bits	4-13
		4.7 A/D and D/A Calibration	4-14

5.	REMOTE CONTROL CONSIDERATIONS	5-1	7.4.5	Automatic Layer III Line and Bit Rate Fallback	7-29
5.1	Communications PROTOCOL definition	5-2	8.	PSYCHOACOUSTIC PARAMETER ADJUSTMENTS FOR MUSICAM	8-1
5.2	RS232 Considerations	5-4	8.1	Introduction	8-1
5.3	RS485 Considerations	5-4	8.2	History	8-3
5.4	Inband Control of Far End CDQPrima	5-9	8.3	Basic Principle of MUSICAM	8-4
5.4.1	Far End Remote Control Using a Terminal	5-10	8.3.1	MPEG Encoder	8-5
5.5	Windows Remote Control Program	5-11	8.3.2	MPEG Decoder	8-8
5.5.1	Far End Codec Control Using Windows® Control	5-12	8.4	Adjustment of the Perceptual Model—A Tool for the Sophisticated User	8-9
5.6	Remote Control Error Summary	5-12	8.5	Changing Psychoacoustic Parameters	8-12
6.	ANCILLARY DATA FEATURES	6-1	8.6	MUSICAM USA psychoacoustic model parameters	8-16
6.1	Ancillary Data Basics	6-1	8.6.1	Parameter A - J (0 - 9)	8-16
6.2	Ancillary Data Format	6-3	8.6.2	Parameter K (10) — Joint Minimum Subband	8-17
6.3	RS232 Ancillary Data	6-4	8.6.3	Parameter L (11) Anticorrectional Factor	8-17
6.4	Other RS232 Data	6-6	8.6.4	Parameter M (12) Limit Subbands	8-17
6.5	SMPTE Time Code	6-7	8.6.5	Parameter N (13) Threshold of Hearing Table	8-18
6.6	Virtual Links, Cue LEDs, Relay Closures And Simulated Switches	6-9	8.6.6	Parameter O (14) Stereo/Dual Mono Safety Margin	8-18
6.7	Ancillary Data With Independent Mono Operation	6-9	8.6.7	Parameter P (15) Jnt..SKF.ISO	8-18
7.	PLL BASICS	7-1	8.6.8	Parameter Q (16) Joint Boundary Adjustment	8-19
7.1	PLL Events	7-1	8.6.9	Parameter R (17) Demand Minimum Factor	8-19
7.1.1	Bit Error Rate Detection	7-2	8.6.10	Parameter S (18) Stereo/Dual Mono used subbands	8-19
7.1.2	Out Of Frame Counter	7-6	8.6.11	Parameter T (19) Joint Frames Count	8-19
7.1.3	Silence / Audio Detection	7-7	8.6.12	Parameter U (20) Peak <.49> RMS	8-20
7.1.4	Timers	7-9	8.6.13	Parameter V (21) 3 dB <.499> 6 dB	8-20
7.1.5	Optically Isolated Inputs (option)	7-9	8.6.14	Parameter W (22) Adjustment Subband 3	8-21
7.1.6	Simulated Switches	7-10	8.6.15	Parameters X (23) - Z (25) Adjustment Subband 2 - 0	8-21
7.1.7	Status Event	7-11	8.6.16	Parameter { (26) Subband hang Time	8-21
7.1.8	Link Event	7-12	8.6.17	Parameter (27) Scale Factor Adjustment	8-21
7.2	PLL Actions	7-12	8.6.18	Parameter (28) Mono used subbands	8-21
7.2.1	Physical Actions	7-13	8.6.19	Parameter (29) Joint Stereo used subbands	8-22
7.2.2	Link Actions	7-15			
7.2.3	Virtual Actions	7-16			
7.3	Event To Action Logic	7-16			
7.4	PLL Examples	7-22			
7.4.1	Auto Detection of Incoming Call Format	7-22			
7.4.2	Auto Detection of Incoming Call Algorithm - Layer II or Layer III	7-25			
7.4.3	Dial On Audio - Disconnect On Silence	7-27			
7.4.4	Automatic STL Backup	7-28			

8.6.20	Parameter (30) Mono Safety Margin	8-22	Cable C1500 — Prima 110 And 120 AES Adapter	A-2
8.6.21	Parameter (31) Joint Stereo Safety Margin	8-22	Cable C1600 — SMPTE Time Code Cable	A-2
			Cable C1700 — Ancillary Data And RS232 Cable	A-2
9.	WHAT'S LEFT	9-1	Cable C1800 — Rear Panel RS232 Remote Control Cable	A-3
9.1	Security	9-1	Cable C1900 — Rear Panel RS485 Remote Control Cable	A-3
9.2	On Line Help	9-5	Cable C2000 — Front Panel RS212 Remote Control Cable	A-3
9.3	Factory Defaults And User Profiles	9-6		
9.3.1	Resetting Factory Defaults	9-7		
9.3.2	Creating A User Profile	9-8		
9.3.3	Reloading User Defaults (User Profile)	9-9		
9.4	Option Installation	9-9	APPENDIX B— REAR PANEL CONNECTORS	B-4
9.4.1	A1000 AES/EBU Digital Audio I/O	9-9	CDQPrima 1xx Series	B-4
9.4.2	A1100 And A1200 Optical Isolated Control Inputs And Relay Outputs	9-10	Audio Input	B-4
9.4.3	A2100 SMPTE Time Code Reader/Generator	9-11	Audio Output	B-4
9.4.4	A1300 Optical Digital Audio I/O	9-12	AES/EBU	B-4
9.5	Software Maintenance, and Upgrading, Version and serial Numbers	9-12	RS232/RS485 Remote Control	B-4
			Ancillary Data	B-4
			Alarm Relay	B-5
			Sync Data - Opto/Relay	B-5
			CDQPrima 2xx Series, Prima LT Series	B-5
			Audio Input	B-5
			Audio Output	B-5
			AES/EBU	B-6
			RS232/RS485 Remote Control	B-6
			Ancillary Data	B-6
			Alarm Relay	B-6
			Opto Inputs	B-7
			Relay Outputs	B-7
			RS232	B-7
			Front panel remote control	B-7
			RS485	B-7
			SMPTE Time code	B-8
			DIF101, DIF102	B-8
			X.21	B-8
			V.35	B-8
			APPENDIX C — FACTORY DEFAULTS	
			C-9	
			APPENDIX D — OPTO-ISOLATOR AND RELAY I/O	D-14
			Opto Inputs	D-14
			Relay Outputs	D-14
APPENDIX A	— CABLE DIAGRAMS			
A-1				
Cable C1300.	DB15M To V.35 Block	A-1		
Cable C1400 —	DB15M To V.35 DB25M	A-1		

APPENDIX E — CDQPRIMA LCD MENU TREE

E-15

APPENDIX F— ISDN ORDERING AND PROVISIONING	F-23
North American ISDN Ordering Contacts	F-23
North American ISDN Provisioning	F-23
FAX-PAGE 1	F-24
AT&T 5ESS Custom	F-24
FAX-PAGE 2	F-25
AT&T 5ESS - National ISDN 1	F-25
FAX-PAGE 3	F-26
AT&T 5ESS — Custom	F-26
AT&T 5ESS — National ISDN	F-26
Northern Telecomm DMS-100 BC-35 National ISDN 1	F-27
FAX-PAGE 4	F-27
FAX-PAGE 5	F-28
Northern Telecomm DMS-100 BC-35 National ISDN 1	F-28

APPENDIX G — SPECIFICATIONS

G-29

APPENDIX H— ONE YEAR LIMITED WARRANTY	H-34
--	------

