

Table of Contents

Introduction	i	2.6.7	AES/EBU Digital Audio I/O (9, 10)	2-9
CHAPTER 1		2.6.8	S/PDIF Digital Audio I/O (9, 10)	2-9
1. cdoPrima Overview	1-1	2.6.9	Opto/Relay I/O (100 Series) (11)	2-10
1.1 Model 110 Description	1-4	2.6.10	RS232 Port (200 Series) (12)	2-10
1.2 Model 120 Description	1-4	2.6.11	Sync Data (200 Series) (13)	2-10
1.3 Model 210 Description	1-5	2.6.12	RS485 Port (200 Series) (14)	2-10
1.4 Model 220 Description	1-5	2.6.13	SMPTE Time Code (200 Series) (15)	2-10
1.5 Model 230 Description	1-5	2.6.14	Relay Outputs (200 Series) (16)	2-11
1.6 cdoPrima Features	1-6	2.6.15	Optically Isolated Inputs (200 Series) (17)	2-11
1.6.1 Mechanical Features	1-6	2.6.16	Optical Digital Audio I/O (18)	2-11
1.6.2 Audio and Time Code	1-7			
1.6.3 Ancillary Data	1-7	CHAPTER 3		
1.6.4 Audio Compression	1-8	3. The cdoPrima Keypad and Display		3-1
1.6.5 Control Features	1-8	3.1 Character Display (Models 110, 120, 210 & 220)		3-1
1.6.6 Pre-Programmed Quick-Configurations	1-10	3.2 Graphics Display (Model 230)		3-2
1.6.7 Auto Detection of Incoming Calls	1-10	3.3 LCD Display Contrast Adjustment		3-2
1.6.8 On-Site Software Upgrades	1-11	3.4 Front Panel Controls		3-3
1.6.9 Digital Interface Modules	1-11	3.4.1 Cursor Keys (All Models)		3-3
CHAPTER 2		3.4.2 Alphanumeric Keypad (All Models)		3-4
2. Unpacking & Inspection	2-1	3.4.3 Dial Keypad (All Models)		3-4
2.1 Location of Units	2-1	3.4.4 Dial Setup Keys (All Models)		3-4
2.2 Environmental Considerations	2-1	3.4.5 Menu Keys (Models 120, 220 & 230 only)		3-5
2.3 Configuration Dependencies	2-2	3.4.6 Headphone Keys (Models 120, 220 & 230 only)		3-6
2.4 Remote Control Considerations	2-2	3.4.7 Cue Keys (Models 120, 220 & 230 only)		3-7
2.4.1 Remote Control of Models 110 and 120	2-2	3.4.8 Level Meter Control Keys (Model 230)		3-7
2.4.2 Remote Control of Models 210, 220, and 230	2-3	3.4.9 Measurement Keys (Model 230 only)		3-8
2.5 Connections to the Network	2-3	3.4.10 Function Keys (Model 230 only)		3-8
2.5.1 V.35 Using the DIF102 Digital Interface Module	2-4	3.4.11 Keypad Beeper		3-9
2.5.2 X.21, RS422/RS449 Using the DIF101 Digital Interface Module	2-4	3.5 Front Panel Status Indicators		3-9
2.5.3 ISDN Using the TA101 Digital Interface Module	2-5	3.5.1 Encoder and Decoder Status LEDs		3-9
2.5.4 ISDN Using the TA201 or TA301 Digital Interface Module	2-6	3.5.1.1 PLL		3-9
2.6 Rear Panel Connectors	2-6			
2.6.1 Power & Power Switch (1, 2)	2-6			
2.6.2 Analog Audio I/O (3, 4)	2-7			
2.6.3 Digital Interface Module Ports (5)	2-7			
2.6.4 Alarm Port (6)	2-7			
2.6.5 Remote Control Port (7)	2-8			
2.6.6 Ancillary Data Port (8)	2-9			

3.5.1.2	MONO	3-10
3.5.1.3	DMONO	3-10
3.5.1.4	JSTEREO	3-10
3.5.1.5	STEREO (230 only)	3-10
3.5.1.6	MUSICAM	3-10
3.5.1.7	G.722	3-10
3.5.1.8	AES/EBU (Encoder only)	3-10
3.5.1.9	ANALOG (Encoder only)	3-11
3.5.1.10	SUM (230 only)	3-11
3.5.1.11	ACE (230 only)	3-11
3.5.1.12	DPLL (230 only)	3-11
3.5.1.13	CCS (230 only)	3-11
3.5.1.14	ALG1 (230 only)	3-11
3.5.1.15	H.221 (230 only)	3-12
3.5.1.16	CCSIMUX (230 only)	3-12
3.5.1.17	FRAMED (decoder only)	3-12
3.5.1.18	BER (Decoder only)	3-12
3.5.2	Status	3-12
3.5.2.1	SCUE1	3-12
3.5.2.2	RCUE1	3-12
3.5.2.3	DIF1, DIF2, DIF3, DIF4, DIF5 and DIF6	3-12
3.5.3	Level LEDs (Model 120, 220 & 230 only)	3-13
3.5.3.1	Peak & Average Level LEDs	3-13
3.5.3.2	Stereo Image Display	3-13
3.5.3.3	Correlation Display	3-14
3.5.3.4	Message Display	3-14
3.5.3.5	Selective Dimming	3-14
3.5.3.6	Headphone Status Indicators	3-14
3.6	Front Panel Connectors	3-14
3.6.1	Headphone Jack (Model 120, 220 & 230 only)	3-14
3.6.1.1	Headphone Level Adjustment and Source Selection	3-15
3.6.2	Front Panel Remote Control Port (Model 120, 220 & 230 only)	3-15
3.7	Cooling Fan	3-16

CHAPTER 4

4.	Command and Control Summary	4-1
4.1	Menu Navigation using Keypad and Display	4-2
4.2	Remote Control Considerations	4-3
4.2.1	Remote Control	4-3
4.3	Computer or Terminal Control	4-4
4.4	Windows® Control	4-4
4.5	Configuring The Remote Control Ports	4-5
4.5.1	RS485 Terminations	4-7
4.6	Far-End Remote Control	4-7

CHAPTER 5

5.	Digital Interface and Terminal Adapter Setup	5-1
5.1	Digital Interface Setup	5-1
5.2	Terminal Adapter TA101 Configuration.	5-3
5.2.1	Switch Type (North America and Germany Only)	5-4
5.2.2	Service Provider ID (SPID) Number (North America Only)	5-5
5.2.3	Identification (ID) Number (North America Only)	5-6
5.2.4	Multiple Subscriber Number (MSN — Europe Only)	5-6
5.2.5	Local Check (North America Only)	5-6
5.2.6	LLC State (United Kingdom and North America)	5-6
5.2.7	Sub Address, EAZ (Germany), Interface Mode and Inband	5-7
5.2.8	Reset	5-8
5.3	Terminal Adapter TA201 and TA301 Configuration for North America	5-8
5.3.1	Select Country	5-9
5.3.2	Switch Type	5-10
5.3.3	Service Provider ID (SPID) Number	5-10
5.3.4	Identification (ID) Number	5-11
5.3.5	Sub-Address And Interface Mode	5-11
5.3.6	Reset	5-12
5.4	Terminal Adapter TA201 Configuration, Non-North American Operation	5-12
5.4.1	Select Country	5-13
5.4.2	Switch Type (Germany Only)	5-13
5.4.3	LDN / MSN Number	5-13
5.4.4	Sub-Address And Interface Mode	5-13
5.4.5	LLC (Low Level Command) State (UK Only)	5-14
5.4.6	Reset	5-14
5.5	Terminal Adapter Configuration Storage and Recall	5-14
5.6	Other TA Parameters	5-15
5.7	Digital Interface Connect Time And Status	5-17
5.8	Alphanumeric Characters in Dial String	5-18

CHAPTER 6

6.	Two Steps To Success	6-1
6.1	Go Configure	6-1

Index

A

AES/EBU, 2-2
 Alarms, 2-7
 Algorithm mode, 6-5
 Dual Mono, 6-2
 Joint Stereo, 6-2
 Selection, 6-13
 Stereo, 6-2
 Algorithms, 6-5
 G.722, 1-8, 6-4
 Layer II, 1-8, 6-3
 Layer III, 1-8, 6-2
 MUSICAM, 1-8, 6-3
 Selection, 6-13, 6-17
 Ancillary data, 1-7, 1-9, 2-9, 2-10
 Bit rates, 1-7
 Mux mode, 1-7
 Nomux mode, 1-7
 RS232, 2-9, 2-10
 Time code, 2-10
 Audio I/O, 2-7, 2-9, 2-11, 6-12, 6-15, 6-18
 Auto detection, 1-10

B

Bit rate
 Selection, 6-12, 6-17
 Bit rates, 3-5, 6-5

C

Cable lengths, 2-2
 Cables
 Ancillary data, 2-9
 Digital audio, 2-2, 2-9
 Opto-isolators, 2-11
 Relay, 2-11
 Remote control, 2-9, 4-4
 Call termination, 6-24
 CDQ1000, 3-11
 CDQ2000, 3-11, 3-12
 Commands
 CAA, 5-16
 CAC, 5-16
 CBZ, 7-5
 CCC, 5-8, 5-10, 5-12, 5-13
 CCD, 5-17, 5-18
 CCR, 5-17, 5-18
 CCS, 5-17, 5-18
 CCV, 7-5

CDC, 5-17
 CDF, 7-1
 CDT, 5-1, 5-2
 CFB, 4-6
 CFE, 4-6
 CFP, 4-6
 CGH, 6-13
 CHK, 3-8, 7-4
 CHU, 3-5
 CIB, 5-3, 5-7
 CID, 4-6
 CIF, 3-4, 5-1, 5-2
 CKI, 5-18, 6-23
 CLB, 5-16
 CLC, 5-3, 5-6
 CLD, 5-3, 5-6, 5-8, 5-11, 5-12
 CLL, 5-3, 5-12
 CPC, 4-6
 CPU, 7-1, 7-3
 CRB, 4-6
 CRD, 5-16
 CRE, 4-6
 CRI, 4-6
 CRM, 4-6
 CSA, 5-3, 5-7, 5-8, 5-11, 5-12
 CSD, 3-5
 CSE, 3-5
 CSI, 5-4, 5-6, 5-9, 5-10
 CSW, 5-4, 5-9, 5-10, 5-12, 5-13
 CTA, 5-14, 5-15
 CTB, 5-14, 5-15
 CTC, 5-16, 5-17
 CTD, 5-14, 5-15
 CTE, 5-14, 5-15
 CTF, 5-4, 5-7, 5-9, 5-11, 5-12
 CTN, 5-15
 CTO, 5-16
 CTP, 5-16, 5-17
 CTR, 5-4, 5-8, 5-9, 5-12, 5-14
 CVR, 5-17
 DAL, 6-15, 6-17
 DBR, 6-15, 6-17
 DCO, 6-15
 DCS, 6-15, 6-19
 DDA, 6-20
 DIN, 6-15, 6-16
 DLI, 6-15, 6-17
 DLV, 6-15, 6-21
 DMU, 6-15, 6-19
 DRS, 6-21
 DSP, 6-19
 DSS, 6-15

EAD, 6-20
 EAI, 6-12
 EAL, 6-12, 6-13
 EAM, 6-12, 6-13
 EBR, 6-12, 6-13
 ECR, 6-21
 ECS, 6-12, 6-18
 EEP, 6-21
 ELI, 6-12, 6-14
 ELV, 6-12, 6-21
 EMM, 6-12, 6-18
 EOR, 6-21
 EPI, 6-21
 EPR, 6-21
 ESD, 6-19
 ESP, 6-19
 ESR, 6-12, 6-14
 ESS, 6-12
 ETI, 6-12
 MBX, 7-5

D

Decoder
 Algorithm, 6-15, 6-17
 Bit rate, 6-15, 6-17
 Calibration
 Clip level, 6-15, 6-21
 Copy/Swap, 6-15, 6-19
 Independent, 6-15
 Level adjust, 6-21
 Line format, 6-15, 6-16
 Mute, 6-15, 6-19
 Status, 6-15
 Defaults
 Factory, 7-2
 User profile, 7-3
 Dialing, 3-4, 6-22, 6-23
 Alphanumeric characters, 6-23
 Call termination, 3-5
 Manual, 3-4, 3-5
 Speed dial, 3-5
 DIF101, 2-4, 5-2
 DIF102, 2-4, 5-2
 Digital audio, 2-9, 2-11, 6-12
 Digital Interface Module, 1-11, 2-4, 2-5, 2-6, 2-7, 5-1
 Display
 ACE LED, 3-11
 AES/EBU LED, 3-10
 ALG1 LED, 3-11

- Analog LED, 3-11
- BER LED, 3-12
- Bit errors, 3-2
- CCS LED, 3-11
- CCSIMUX LED, 3-12
- Character, 3-1
- Contrast, 3-1, 3-2, 7-5
- Correlation, 1-5, 1-6, 3-7, 3-14
- DIF LEDs, 3-5, 3-12
- DPLL LED, 3-11
- Dual mono LED, 3-10
- Encoder Status, 3-9
- Framed, 3-2
- Framed LED, 3-12
- G.722 LED, 3-10
- Graphics, 3-2, 3-8
- H.221 LED, 3-12
- Headphone LEDs, 3-6, 3-14
- Joint stereo LED, 3-10
- LED brightness, 3-14
- Level, 3-7, 3-13
- Loopback, 3-2
- Message display, 3-14
- Mono LED, 3-10
- MUSICAM LED, 3-10
- Overload, 3-2
- Peak, 3-7
- Phase, 3-2, 3-8
- PLL LED, 3-9
- RCUE LED, 3-7, 3-12
- SCUE LED, 3-7, 3-12
- Spectrum analyzer, 3-2, 3-8
- Status, 3-1, 3-9, 3-12
- Stereo image, 1-5, 1-6, 3-7, 3-8, 3-13
- Stereo LED, 3-10
- SUM LED, 3-11
- Display contrast, 7-5

E

- Encoder
 - Algorithm, 6-13
 - Algorithm mode, 6-12, 6-13
 - Algorithms, 6-12
 - Audio I/O, 6-12
 - Bit rate, 6-12
 - Calibration
 - Clip level, 6-12, 6-21
 - Copy/Swap, 6-12, 6-18
 - Header bits, 6-21
 - Level adjust, 6-21
 - Line format, 6-12, 6-13
 - Mono mix, 6-12, 6-18
 - Sample rate, 6-12, 6-14
 - Sine detector, 6-19
 - Status, 6-12
 - Timing, 6-12
- Error concealment, 6-19

F

- Factory defaults, 3-8, 7-1, 7-2

- Reset, 7-2
- Features, 1-1
 - Algorithms, 1-1
 - Ancillary data, 1-2, 1-4, 1-5, 1-7
 - Audio, 1-2, 1-7
 - Audio compression, 1-8
 - Auto detection, 1-10
 - Control, 1-3, 1-8
 - Digital audio, 1-4, 1-5, 1-7
 - Digital Interface Modules, 1-11
 - Graphic display, 1-5
 - Headphone, 1-4, 1-5, 1-6
 - Keypad, 3-3
 - Mechanical, 1-2, 1-6
 - Options, 1-2
 - Quick Configuration, 1-10
 - Relays, 1-4, 1-5
 - Remote control, 1-4, 1-9
 - Time code, 1-7
- Front panel, 3-14
- Function keys, 7-4

H

- H.221, 3-12, 6-14, 6-17
- Hangup, 6-24
- Headphone, 3-6, 3-7, 3-14

I

- Input level, 1-7, 2-7
- Installation, 2-1
- ISDN, 1-11, 2-2, 5-1, 5-3
- ISO/MPEG Layer III, 3-10

J

- J.52, 3-12

K

- Keypad, 3-3, 4-1, 4-2
 - Alphanumeric keys, 1-9, 3-4, 4-1, 4-2
 - Beeper, 3-1, 3-9
 - Cue keys, 3-7
 - Cursor keys, 1-9, 3-3, 3-4, 4-2
 - Dial keys, 1-9, 3-4
 - Function keys, 3-8
 - Headphone keys, 1-9, 3-6
 - Hot keys, 1-9, 3-8
 - Level keys, 3-7
 - Measurement keys, 3-8
 - Menu keys, 3-5
- Keypad beeper, 7-5

L

- Level LEDs, 3-7
- Line format
 - Selection, 6-13, 6-16

- Loopback, 3-2
- Loopback indicator, 3-2

M

- Manual dialing, 6-22
- Menu
 - Navigation, 3-3, 4-2
 - tree, 3-3, 3-4, 3-5, 4-1, 4-2
- Music Line, 1-10, 3-12

N

- Network connections
 - ISDN, 2-5, 2-6
 - RS422, 2-3, 2-4
 - RS449, 2-3
 - V.35, 2-3, 2-4
 - X.21, 2-3, 2-4
- Network connections, 2-3
- NT-1, 2-6, 5-3, 5-9

O

- Optical isolators, 1-5, 1-9, 2-10, 2-11
- Overload indicators, 3-2

P

- PKI compatibility, 6-13
- PLL
 - Virtual actions, 1-10
- Power switch, 2-6
- Prima Logic Language, 1-10, 3-4, 3-11, 4-1
- Psychoacoustic parameters, 1-8

Q

- Quick configurations, 6-24
- Quick Configurations, 1-10, 3-4, 3-5, 6-6
 - Editing, 6-30

R

- RCUE, 3-12
- Rear panel connectors, 2-6
- Relay outputs, 2-11
- Relays, 1-9, 2-7, 2-10, 2-11
- Remote control, 2-2, 2-3, 2-8, 3-14, 3-15, 4-3, 4-4
 - Baud rate, 4-6
 - Configuration, 4-5
 - Echo, 4-7
 - Far end, 1-9, 4-4, 4-7, 5-17
 - Inband, 1-9
 - Peripheral equipment, 1-7, 1-9
 - Protocol, 4-7
 - RS232, 2-2, 2-3, 2-8, 4-3, 4-4

- RS485, 2-2, 2-3, 2-8, 4-3, 4-4
- Terminal, 2-2, 4-1, 4-3
- Timer, 4-4
- Windows, 1-9, 2-2, 4-1, 4-3, 4-4, 5-7, 5-11, 5-14
- RS232, 2-10
- RS422, 1-11, 2-4, 5-2
- RS485, 2-10
 - Termination, 4-7

S

- Sample rate
 - Selection, 6-14
- Sampling rates, 1-8, 6-5
- Scale factors, 6-19
- SCUE, 3-12
- Speed dial
 - Editing, 3-5
 - Viewing, 6-29
- Speed Dial, 1-10, 6-7, 6-24
 - Editing, 6-30
- Speed dialing, 6-23
- Status bits, 6-21
- Status indicators, 1-6, 3-9
- Summary alarms, 2-7

T

- Terminal adapter, 3-4, 5-1
 - Auto answer, 5-16
 - Auto reconnect, 5-16
 - Configuration, 5-15
 - Connect time, 5-17
 - Country, 5-9, 5-13
 - EAZ, 5-3
 - ID, 5-3, 5-5, 5-11
 - Inband, 5-3
 - Interface, 5-4, 5-7, 5-11, 5-13
 - LLC, 5-3, 5-6, 5-14
 - Local check, 5-3, 5-5
 - Loopback, 5-16
 - MSN, 5-3, 5-6, 5-13
 - Redial, 5-16
 - Reset, 5-4, 5-8, 5-12, 5-14
 - SPID, 5-4, 5-5, 5-9, 5-10
 - Sub address, 5-3, 5-7, 5-11, 5-13
 - Switch type, 5-4, 5-5, 5-10
 - TA101, 2-5, 3-12, 5-2
 - TA201, 2-6, 5-2, 5-12
 - TA301, 2-6, 5-2
- Terminal Adapter
 - EAZ, 5-7

- ID, 5-6
- Local check, 5-6
- SPID, 5-5, 5-6, 5-10
- Switch type, 5-4, 5-13
- Time code, 1-5, 1-7, 2-10
- Timing, 6-12

U

- Upgrades, 1-11
- User profile, 7-1, 7-3

V

- V.35, 2-4, 5-2
- Virtual actions, 1-9, 1-10

X

- X.21, 1-11, 2-5, 5-2

